



TECHNICAL BULLETIN

CONCRETE & MASONRY INFORMATION FOR THE PROFESSIONAL

EQUIPMENT CHECKLIST FOR DURAGUARD 400 AND DURAGUARD 420 METHYL METHACRYLATE (MMA) COATING SYSTEMS

For a successful installation the following equipment is required:

Surface Preparation

- Shot Blaster
- Shop Vac

Application

- Surface Thermometer & Ambient Thermometer
- Heavy Duty, Variable Speed Drill with Extension Cord
- Long Shaft, Jiffler Type Mixing Blade
- Graduated Glass or Plastic, One Quart Measuring Cup with one-ounce Calibrations
- Large Plastic or Wooden Spoon
- 2 Long Roller Handles & 5-6 Short Nap @ 1/4 inch or less, Solvent Resistant Roller Covers
- 2 Long Handled, Solvent Resistant, 1/8 inch Serrated Squeegees
- 2 Empty, Clean Metal Pails
- MEK or Ketone Solvent, Xylene is **not** Suitable
- Spiked Shoes, either golf or aerator type
- Wet Mil Thickness Gauge
- Poly Sheeting, Shop Rags, Safety Glasses, Solvent Resistant Gloves. Screwdriver



ChemMasters, Inc.

300 Edwards Street, Madison, Ohio 44057

Phone: (800) 486-7866 * (440) 428-2105 * Fax: (440) 428-7091

www.chemmasters.net